

Service Information

Domestic Appliances and Personal Care

1998-05-07

Mixer	HR 1530	HR 1538	HR 1548
	HR 1534	HR 1539	
	HR 1535	HR 1540	

DAP165

Use in the appliances the cord **4822 321 11432 (item 5)** in stead of the published one (4822 321 10622)

See Service Manual: 4822 729 21708 for HR 1530 and HR 1540
4822 729 21709 for HR 1534 and HR 1535
4822 729 21754 for HR 1538 and HR 1548
4822 729 21753 for HR 1539