

Service
Service
Service



HD 2550/A
HD 2550/B
HD 2551/A
HD 2551/B
HD 2553/A
HD 2553/B
HD 2554/B

Philips Domestic Appliances and Personal Care

Service Manual

PRODUCT INFORMATION

Voltage : 220-240V
 Frequency : 50-60Hz
 Power consumption : 1080W
 Color setting : Ivory / Green
 : Ivory / Pearl Blue
 : Lemon / Blue

SERVICE INFORMATION

	HD2550/A HD2550/B HD2551/A HD2551/B	HD2553/A HD2553/B	HD2554/B
Crumb tray	x	x	x
Bun warmer	-	-	x
Dust cover	-	x	-

- Max. timer setting:
 HD253X/A 185 sec. ± 15%
 HD253X/B 160 sec. ± 15%
- In case a technical defect, toaster has to be replaced.
- Only numbered items are serviceable parts.

- 1 Bun warmer Ivory 996500001169
- 2 Crumb tray Zinc Brown 996500001167
- 3 Dust cover blue 996500001168

DFU
 HD2550 / HD2552 West Europe 422200191982
 HD2550 / HD2552 East Europe 422200191992
 HD2551 / HD2554 West Europe 422200192002

