



PRINTER OPTION

PF-9

PARTS CATALOGUE

PF-9 Parts Catalogue

Table of Contents

Assembly (Fig.1).....3

Introduction

The figures which follow depict the major assemblies of the printer or option, broken down into components. Following each figure are the list giving the following information:

- 'Ref No.'Reference number which corresponds to the parts in the figure
- 'Part code'.....Part code which identifies the part
- 'Part description'A brief description of the part
- 'Quantity'.....Quantity of the part used in the printer or option

Only the parts highlighted in BOLD should be ordered. All other parts are for reference only and are not stocked.




Fig.1 - Assembly

Ref No.	Part Code	Description	Quantity
01-001	5SNSP0009737	BRACKET DRIVE ASSY	1
01-002	5SNSP0009738	FRAME RIGHT ASSY	1
01-003	5SNSP0009739	FRAME LEFT ASSY	1
01-008	5SNSP0009745	BUSHING	1
01-010	5SNSP0009745	BUSHING	1
01-011	5SNSP0009746	PWB CONTROL	1
01-012	5SNSP0009747	SENSOR PA-5	1
01-013	5SNSP0009748	CONN. CORD ASSY	1
02-001	5SNSP0009749	BRACKET DRIVE	1
02-002	5SNSP0009750	MOTOR ASSY	1
02-003	5SNSP0009752	GEAR JOINT Z15	1
02-004	5SNSP0009753	GEAR IDLE Z15	2
02-005	5SNSP0009754	GEAR Z25-Z40	1
02-006	5SNSP0009755	PLATE EARTH	1
02-007	5SNSP0009751	PLATE ARM ASSY	1
04-002	5SNSP0009759	FOOT	2
05-002	5SNSP0009759	FOOT	2
06-001	5SNSP0009761	COVER PANEL ASSY	1
06-002	5SNSP0009762	PWB PANEL	1
06-003	5SNSP0009763	CONN. CORD ASSY	1
07-001	5SNSP0009766	COVER TOP	1
07-002	5SNSP0009767	PE SENSOR ASSY	1
07-003	5SNSP0009768	ACTVATOR SENSOR	1
07-004	5SNSP0009769	CHANNEL REAM	2
07-005	5SNSP0009770	PLATE EARTH	3
07-006	5SNSP0009771	SHEET COVER	1
07-007	5SNSP0009772	GUIDE PLATE	2
07-008	5SNSP0009773	SPRING GUIDE PAPER	2
07-009	5SNSP0009774	CONNECTER ASSY	1
08-001	5SNSP0009776	PLATE BASE	1
08-002	5SNSP0009777	COVER SENSOR REAR	1
08-003	5SNSP0009778	PWB SENSOR REAR	1
08-004	5SNSP0009779	COVER SENSOR WIDE	1
08-005	5SNSP0009780	PWB SENSOR WIDE	1
08-006	5SNSP0009781	SPRING ACTUATER	4
08-007	5SNSP0009782	CONN. CORD ASSY	1
08-008	5SNSP0009783	NYLON CLAMP	4
09-001	5SNSP0009784	ROLL FEED	1
09-002	5SNSP0009785	GEAR FEED Z30	1
10-001	5SNSP0009786	ROLL DRIVE	1
10-002	5SNSP0009787	GEAR DRIVE Z15	1
10-003	5SNSP0009745	BUSHING	1
11-001	5SNSP0009788	BASE CASSETTE ASSY	1
11-004	5SNSP0009791	GEAR PINION Z16	1
11-005	5SNSP0009792	PLATE BOTTOM ASSY	1

Ref No.	Part Code	Description	Quantity
11-006	5SNSP0009793	SPRING CASSETTE	2
11-007	5SNSP0009794	BACK END ASSY	1
13-001	5SNSP0009800	GUIDE PAPER R	1
13-002	5SNSP0009801	LEVEL LOCK	1
13-003	5SNSP0009802	NAIL R	1
14-001	5SNSP0009804	GUIDE PANEL L	1
14-002	5SNSP0009805	NAIL L	1
14-003	5SNSP0009803	SPRING NAIL	1
16-001	5SNSP0009808	BACK END F	1
16-002	5SNSP0009809	BACK END R	1
16-003	5SNSP0009810	SPRING PRESS	1
17-001	5SNSP0009811	COVER FRONT	1
17-003	5SNSP0009813	ROLL PINCH ASSY	2
18-001	5SNSP0009814	ROLL PINCH	1
18-002	5SNSP0009815	SPRING ROLL PINCH	1