

Service
Service
Service



HD 3345
HD 3346
HD 3348
HD 3349
HD 3350
HD 3352

Philips Domestic Appliances and Personal Care

Service Manual

GENERAL

For this type number **no spare parts** will be available in the after sales period. When the product is defective, it has to be replaced.

